The **Airplane Stand** template for all PowerUp 3.0 and PowerUp Free Flight (2.0) airplan designs. Paper type - 80 to 100 GSM Paper size - A4

Printer setting - Scale 100% borderless

Copyright © 2015 TailorToys L.L.C. All rights reserved. PowerUp® is a trademark of TailorToys L.L.C.

www.poweruptoys.com







The Airplane Stand template for all PowerUp 3.0 and PowerUp Free Flight (2.0) airplan designs. Paper type - 80 to 100 GSM Paper size - A4

Copyright © 2015 TailorToys L.L.C. All rights reserved. PowerUp® is a trademark of TailorToys L.L.C.


www.poweruptoys.com




1. Start with the printed side up. Turn over (from left to right)




2. Fold the lower edge to the upper edge and unfold.




3. Fold the lower edge to the center line and unfold.




4. Fold the upper edge to the center line.




5. Fold the lower edge to the new upper edge.




6. Fold both left and right sides to the printed center line. Unfold.




7. Fold the right edge to the new fold line on the left.




8. Fold the same edge back, along the existing crease line.



9. Fold the left edge to the right edge.



10. Fold the same edge back, along the existing crease line.



11. Fold the edges along the printed crease lines.




12. Bring both left and right flaps to meet in the center. The model becomes 3D now! Next image is from a diferent point of view.


The **Airplane Stand** template for all PowerUp 3.0 and PowerUp Free Flight (2.0) airplan designs.
Paper type - 80 to 100 GSM
Paper size - A4

Copyright © 2015 TailorToys L.L.C. All rights reserved. PowerUp® is a trademark of TailorToys L.L.C.


www.poweruptoys.com




13. This is the result. Next image is enlarged.




14. Bring the dotted red line to the full red line, while making a new crease (*) and using the existing one (#).




15. Repeat on the other side.



16. Lock the back corner by folding it with a 45 degrees fold line.



17. Repeat with the other corner.



18. Fold the front flap up, to create a name tag



19. Write in your airplane's name on the available tab.Your stand is ready!